

Toyota Sequoia 2" Rear Lift Kit

1. Place the vehicle on a level surface.
2. Block the front wheels to prevent vehicle from moving in either direction.
3. Make sure parking brake is on.
4. Lift the truck from the center of the rear differential housing, leaving the jack in place to support the differential.
5. Support the vehicle with jack stands from support points on the frame.
6. Remove the rear wheels.
7. Carefully lower the floor jack until the suspension is fully dropped down.
8. Compress the rear coil spring with a "hook" type compressor.
9. Place the new lift spacer between the rubber bottoming cone and the rear coil spring with the spacer center locating flange facing downward.
10. Release the spring compressor allowing the coil spring to expand, making sure that the spacer, the bottom cone, and the spring are properly positioned.
11. Replace the wheels and torque to factory specs.