



SAFETY WARNING!

Always use the correct tools, and wear safety goggles and gloves. Always use jack stands or a locking lift. We recommend professional installation by a licensed mechanic.

VEHICLE RIDE WARNING!

Trucks with lift kits or leveling kits installed have a higher center of gravity. Aggressive direction changes may cause a tip over. Always drive carefully and obey the speed limit.

2005-2008 Ford SuperDuty 4x4 Lift and Level Kit Installation

1. Lift truck on two post lift and remove tires
2. Support the differential with a pair of screw jacks or with a transmission jack
3. Disconnect the front shocks and the sway bar links
4. Lower the front differential down, allowing the top of the spring to come loose. Be careful not to strain the ABS wiring or brake lines.
5. Remove the rubber isolator and install it over the snout on the steel leveling kit
6. Place the steel leveling kit on the spring and lift the differential back into position
7. If purchased, install the shock extensions or longer shocks
8. Reconnect the shocks and sway bar links
9. Reinstall tires and set the toe. The other alignment angles should be within spec, but you may wish to double check them.



Alignment Specifications:

Caster Left	Caster Right	Camber Left	Camber Right	Toe-in	Need Camber Kit?
1.5	1.5	1/4	1/4	-1/16	No