

2005-2017 Nissan Frontier Body Lift

Loosen steering shaft bolt through the driver wheel well and also the bolt where the steering shaft meets the steering rack, but do not remove.

Loosen all body bolts, but do not remove yet.

(If you have the factory chrome bumper, you will need to modify/fabricate or purchase front bumper relocation brackets.)

We recommend starting with installing one side at a time.

Start with the cab, remove the body bolts from one side. Slowly lift the body on that side so that the body separates from the frame at a secure point under the cab with a wood block. Keep an eye out for wires, hoses, or anything that may bind or kink. Lift enough to place the 2x3 lift pucks in between the body and the frame at the body mounts. Loosely install the new hardware (we do recommend using thread locker if available). Follow the same steps for the opposite side. Once finished, torque body mount bolts to 55 ft. lbs. or factory torque specifications.

Replace the upper radiator hose with the new supplied hose. Check fluid level after replacement, fill to factory specification.

Tighten the steering shaft bolt that was loosened through the driver wheel well, and the bolt at the steering rack.

Moving onto bed, remove body bolts from one side. Slowly lift the bed on that side so that the bed separates from the frame at a secure point under the bed with a wood block. Keep an eye out for wires, hoses, or anything that may bind or kink. Lift enough to place the 2x2 lift pucks in between the bed and the frame at the body mounts. Loosely install the new hardware (we do recommend using thread locker if available). Follow the same steps for the opposite side. Once finished, torque the body mount bolts to 55 ft. lbs. or factory torque specifications.

If you choose to relocate the rear factory bumper, remove the bumper and make a template that moves the holes in the bumper down directly 2 inches. Drill the new wholes and reinstall the bumper. May need to trim if the lower outer portions of the bumper protrude with the frame upon install.